



SAFETY GLASSES REQUIRED



GLOVES REQUIRED



DUST MASK REQUIRED

Revision: 03.14

Required Tools:

- Patience
- Heavy duty scissors or utility knife
- Posterboard, heavy paper - optional
- 3M Super Trim adhesive or other spray adhesive

PRO TIP - Use poster board or butcher paper to make a template. For surfaces with severe bends, it may be necessary to cut relief lines or wedges to get product to conform. Transfer template to HP Stealth Shield and cut.

HP Stealth Shield

Heatshield Products, Inc.
www.heatshieldproducts.com
tech@heatshieldproducts.com
(760) 751-0441

© Heatshield Products, Inc.

1. Pre-fit HP Stealth Shield to floor or desired body panel, measure twice cut once.
2. Make and cuts and modifications to the HP Stealth Shield now. If you are installing under carpet, skip to Step 5.
3. For headliners and vertical surfaces only. Use 3M Super Trim or Super 77 Adhesive. After HP Stealth Shield has been pre-fit and cut, spray back of cloth and panel or component you are applying Stealth Shield to.
4. Allow adhesive to get tacky and press Stealth Shield into place. Start on one edge of panel or component and work out slowly to ensure no "bubbles" occur. Air bubbles will cause the material to not stick and fall off. Press firmly for 2 minutes.
5. Install carpet, headliner, or door panel on top of HP Stealth Shield.
6. *Cruise cooler!*